




USER MANUAL

parasol ELEGANT

VIS PROMOTEX d.o.o.
adress: Adolfa Wisserta 3/a, 42000 Varaždin, CROATIA


e-mail: info@vis-cro.com
www.vis-cro.com
online store: shop.vis-cro.com

0. CENTRAL POLE ASSEMBLY



Before using parasol with two-section pole it is mandatory to connect both part of the central pole firmly by screw in clockwise one into the other.

1. OPENING THE PARASOL




Step 1

Pay attention to persons and objects in the vicinity before opening the parasol!


Step 2

Gently, without using any force, extend the parasol's central ribs, in the opposite direction to the position of the central pole.



Step 3

Hold the handle with both hands and slowly push upwards to desired height - the mechanism automatically secures the parasol




2. CLOSING THE PARASOL



Step 1

Pay attention to persons and objects in the vicinity before closing the parasol!

Press the safety button and using both hands slowly pull the handle downwards.



Step 2



Step 3

In the final stage of closing hold the parasol arms to prevent automatic opening.

3. NOTICES



IMPORTANT NOTICE!

Opening and closing the parasol in any way not specified in these instructions is not recommended. While opening and closing the parasol pay attention to persons and objects in the vicinity.

4. PROTECTION AND SAFETY

- Parasols provide protection from the sun.
- Safe to use in winds up to 7.9 m/s wind speed. Using the parasol beyond the above mentioned wind speed is not completely safe and it needs to be closed.
- Parasol must be firmly fixed to the parasol base (tighten the base screw into the hole on the parasol's central pole).

5. WARRANTY

Warranty does not cover any mechanical, abrasive and chemical abuse or any other damages caused by improper warehousing and distribution, improper cleaning and handling or similar improper activities that could result in damaging the parasol or parasol cover or any of their parts.